


UNG-58.S1

USER'S MANUAL



TECHNICAL SPECIFICATIONS

- Manual winding movement UNG-58.S1 with day corrector at 10 o'clock and moon phase
- Number of jewels: 20
- 28,800 vibrations/hour
- Power reserve: Approx 60 hours

DISPLAY / FUNCTIONS

- 1 Hour hand
- 2 Minute hand
- 3 Small seconds hand
- 4 24 hour hand
- 5 Date indicator hand
- 6 Day indicator
- 7 Month indicator hand
- 8 Moon phase
- 9 3 position crown
 - I Rest and winding position
 - II Rapid date, month and moon phase correction position
 - III Time setting position, with stop second and midnight date and day change
- 10 Corrector (rapid day correction)

USE

WINDING

Crown in position I, not pulled out

Your model has a manual winding movement. If, after having fully wound the watch, you do not wear it for longer than 60 hours, it will stop. You must rewind it by hand to get it moving again. To do this, turn the crown in a clockwise direction. The balance will begin to move after a few turns. Continue to turn the winding mechanism until it cannot be wound up anymore (about 38 times). Please do not wind it up too tightly to avoid damaging the clockwork mechanism. For daily use, we recommend that you wind the watch in the morning before you put it on. The movement spring then has enough power reserve to keep your watch running smoothly until the next day and beyond.

Notes

The accuracy may be influenced by the wearing conditions. There is no stop of the crown at full winding.

SETTING THE TIME

Crown in position III, pulled out

Pull the crown out to position III carefully; the seconds hand (3) will stop. Turn the crown forwards or backwards to the desired time, and then push it back into the rest position I.

Once the hour hand passes the 12 o'clock position, you can see if it is indicating midnight (date and day will change) or midday (date and day will not change).

Advice on how to synchronise your watch

To synchronise the seconds hand (3) with an official time signal (radio/TV/Internet), pull out the crown to position III; the seconds hand will stop. At the signal, push the crown back into the rest position I.

DATE AND MONTH CORRECTION

Crown in position II, intermediate

The date is indicated by the hand (5) and the month in the aperture (7). You will need to re-set the date and month manually after months with less than 31 days.

Pull the crown out to position II and turn it counterclockwise until it displays the desired date and month. Push the crown back into the rest position I. During this operation, your watch will continue running, so the time will not need to be re-set.

Important: Never correct the date between 10 p.m. and 2 a.m.; the movement is changing the date and possibly the month.

MOON PHASE CORRECTION

Crown in position II, intermediate

Pull the crown out to position II and turn it clockwise to correct the moon position, referring to a lunar phase chart. Push the crown back into the rest position I. During this operation, your watch will continue running, so the time will not need to be re-set.

Important: Moon phase correction is impossible between 3 a.m. and 4 a.m.

DAY CORRECTION

Press the corrector as many time as needed (10), to move the disc forward until the desired day is displayed in the aperture (6). During this operation, your watch will continue running, so the time will not need to be re-set.

Important: Day correction is impossible between 9.30 p.m. and midnight.

CARE AND MAINTENANCE

We would advise you to clean your watch regularly (except for the leather strap) using a soft cloth and lukewarm soapy water. After immersion in salt water, rinse your watch in fresh water and leave it to dry completely.

Ensure that you do not leave it in places subject to great temperature and humidity variations, in intense sunlight or near strong magnetic fields.

We recommend you have your watch inspected every 3 to 4 years by your approved dealer or agent. For an irreproachable maintenance service and to ensure the warranty remains valid, always approach an approved dealer or agent.

WATER RESISTANCE PRECAUTIONS

Your watch is water resistant but, following a shock, it may lose its water resistance without you realising. Water resistance must be checked up during its scheduled inspection.

Important: In the event of failure of your watch, entrust it only to an approved dealer or agent (see the warranty).